



## Indigo Power Limited

### Use of System Charging Methodology Statement

#### Electricity Distribution License: Standard License Condition 13 and 14

MAIN AUTHOR

Megan Goss

Head of Regulation and Compliance

27<sup>th</sup> January 2025

APPROVER

Terry Dugdale

Chief Executive Officer

27<sup>th</sup> January 2025

Document Number

IPN-CDCM-001

Current Version

V1.4

#### REVISION HISTORY

Version	Date	Description
V1.0	7th October 2020	Initial Publication
V1.1	23rd January 2023	Review and change to footer
V1.2	31st March 2024	Review, and update
V1.3	22nd April 2024	Review, change to address, dates and footer
V1.4	27 <sup>th</sup> January 2025	EHV Ofgem Approved

## Contents

1.0 Introduction.....	3
2.0 Charging Methodology .....	4
3.0 Loss Adjustment Factors.....	6
4.0 Distribution Use of System Charges.....	6
Glossary .....	7

# 1.0 Introduction

## 1.1 Indigo Power Limited's Distribution Business

Welcome to Indigo Power Limited. Indigo Power Limited is a Distribution Network Operator (IDNO), licensed by the Gas and Electricity Markets Authority (GEMA), to design, build, adopt, operate, and maintain electricity Distribution Systems in Great Britain. Contact us:-



## 1.2 Purpose of this Statement

This Use of System (UoS) Charging Methodology Statement describes the methodology that Indigo Power Limited uses to set charges for Customers connected to our electricity Distribution System.

## 1.3 Indigo Power Limited's License Obligations

Indigo Power Limited must prepare a UoS Charging Methodology approved by GEMA setting out the methodology upon which charges will be made for the use of our electricity Distribution System. We must always comply with this UoS Charging Methodology. The UoS Charging Methodology Statement must be available at all times in a form approved by GEMA.

We are required to review our UoS Charging Methodology Statement annually to ensure that it continues to facilitate the Relevant Objectives set out in Standard License Condition 13.

The Relevant Objectives are:-

- that compliance with the UoS Charging Methodology facilitates the discharge by Indigo Power Limited of the obligations imposed on it under the Electricity Act 1989, as amended by the Utilities Act 2000, and by our Electricity Distribution license;
- that compliance with the UoS Charging Methodology facilitates competition in the generation and supply of electricity and does not restrict, distort, or prevent competition in the transmission or distribution of electricity;
- that compliance with the UoS Charging Methodology results in charges which reflect, as far as is reasonably practicable (taking account of implementation costs) the costs incurred by us in its Distribution Business;
- that so far as is consistent with the three bullet points above, the UoS Charging Methodology, as far as is reasonably practicable, takes account of developments in Indigo Power Limited's Distribution Business; and
- compliance with the Regulation and any relevant legally binding decisions of the European Commission and/or the agency for the Co-operation of Energy Regulators.

In addition, as an IDNO, Indigo Power Limited is required by its license to set its Distribution Use of System (DUoS) charges so that, except without prior written consent of GEMA, the standing charge,

unit rate and any other component of charges shall not exceed the DUoS charges to equivalent domestic customers (connected to a Host Distribution Network Operator's (DNO) networks)<sup>1</sup>.

The above is a synopsis. For a complete understanding you should refer to the following: -

- Electricity Act 1989, as amended by the Utilities Act 2000
- Standard License Condition 13 (SLC13) "Charging Methodologies for Use of System and connection"
- Regulation (EU) 2019/943 of the European Parliament and of the Council of 5 June 2019 on the internal market for electricity (recast).

## **2.0 Charging Methodology**

This section contains the methodology used by Indigo Power Limited to determine the DUoS charges for sites and distributions systems connected to Indigo Power Limited's electricity Distribution System. Wherever possible we will use the same use of system tariffs as our Host DNOs. Sometimes this is not possible and so a fuller explanation is provided below.

The methodology differentiates between those properties connected at Low Voltage (LV) or High Voltage (HV) and those connected as Extra High Voltage (EHV).

### **2.1 Definition of LV, HV and EHV**

LV and HV Properties are defined as:-

- premises connected to the licensee's electricity Distribution System at less than 22 kilovolts excluding those premises connected directly to substation assets that form part of the licensee's electricity Distribution System at 1 kilovolt or more and less than 22 kilovolts where the primary voltage of the substation is 22 kilovolts or more and where the Metering Point is located at the same substation.

EHV properties are defined as:-

- any premises that do not meet the criteria set out above for LV and HV properties.

### **2.2 Methodology to determine DUoS charges for Import to LV and HV Properties**

For demand customers supplied through our network at LV or HV and which fall within the scope of a generic tariff published by the Distribution Services Provider in the Host DNO Area, our applicable use of system tariff is the same as the published tariff that would apply to an equivalent customer supplied by the Distribution Services Provider in the Host DNO Area.

At the time of preparing this statement the method used by Distribution Services Providers to determine the relevant use of system tariffs is called the Common Distribution Charging Methodology (CDCM).

### **2.3 Methodology to determine DUoS charges for Export from LV and HV Properties**

For export customers connected to our network at LV or HV and which fall within the scope of a generic tariff published by the Distribution Services Provider in the Host DNO Area, our applicable use of

---

<sup>1</sup> Equivalent charges are the UoS charges made by the Electricity Distributor which has a Distribution Services Direction that specifies the Distribution Services Area in which the Domestic Premises connected to the licensee's Distribution System. This Electricity Distributor is referred to as the "Host DNO".

system tariff is the same as the published tariff that would apply to an equivalent customer supplied by the Distribution Services Provider in the Host DNO Area and amended as follows:-

- where the Host DNO export tariff for a LV or HV customer contains a unit-based credit, Indigo Power Limited will only pay a unit-based credit in respect of export from LV and HV properties at the same level as that paid by the Host DNO to Indigo Power Limited. This credit will depend on the voltage of the boundary of connection between Indigo Power Limited and the Host DNO.

At the time of preparing this statement, the method used by Distribution Services Providers to determine the relevant use of system tariffs is called the Common Distribution Charging Methodology (CDCM).

## **2.4 Methodology to determine DUoS charges for Import and Export from EHV Properties**

2.4.1 Where an EHV property is connected to Indigo Power Limited's network and the host DNO publishes an All the Way (ATW) import or export DUoS tariff then Indigo Power Limited will apply this tariff. An ATW tariff is defined as the tariff that would apply if the customer were connected directly to the host DNO's network.

2.4.2 Where Indigo Power Limited is not able to set an import or export tariff for an EHV property in accordance with paragraph 2.4.1 or where the tariff would not allow Indigo Power Limited to recover all reasonable costs associated with providing the network to the customer, Indigo Power Limited will calculate the DUoS tariff that applies as the sum of:

- The boundary tariff levied by the host DNO at the boundary with Indigo Power Limited's network in respect of the EHV property; and
- All reasonable costs associated with the fulfilment of Indigo Power Limited's obligation to provide a safe and secure network between the host DNO and the EHV property, and a reasonable rate of return on the assets deemed to be used by the customer. This will include an allocation of direct and indirect costs, network rates, transmission exit charges and depreciation.

2.4.3 Where an EHV property is connected to a distribution system that is connected to an IDNO network, Indigo Power Limited will determine a boundary equivalent price that applies at the boundary between the IDNO network and the distribution system to which the customer is connected. The boundary equivalent price will be calculated based on the principles set out in paragraph 2.4.1 and 2.4.2.

### **3.0 Loss Adjustment Factors**

Where Indigo Power Limited's network connects to the transmission system via the networks of other licensed distributors operating within the same Grid Supply Point group, the loss adjustment factors for connections other than EHV will be replicated to those of the Host DNO.

EHV loss adjustment factors are calculated on a site-specific basis. In calculating the Indigo Power Limited component of the EHV site specific loss adjustment factors Indigo Power Limited will adopt the methodology principles used by the Host DNO for each distribution services area in which Indigo Power Limited operates.

### **4.0 Distribution Use of System Charges**

Indigo Power Limited's DUoS charges are published in a separate SLC14 Statement which can be found on our website [indigonetworks.co.uk](http://indigonetworks.co.uk)

# Glossary

G.1 The following definitions, which can extend to grammatical variations and cognate expressions, are included to aid understanding:

Term	Definition
Customer	<p>A person to whom a User proposes to supply, or for the time being supplies, electricity through an exit point, or from whom, a User or any relevant exempt supplier, is entitled to recover charges, compensation or an account of profits in respect of electricity supplied through an exit point;</p> <p>Or</p> <p>A person from whom a User purchases, or proposes to purchase, electricity, at an entry point (who may from time to time be supplied with electricity as a Customer of that User (or another electricity supplier) through an exit point).</p>
Distribution Network operator (DNO)	An electricity distributor that operates one of the fourteen distribution services areas and in whose electricity distribution license the requirements of Section B of the standard conditions of that license have effect.
Distribution System	<p>The system consisting of (wholly or mainly) of electric lines owned or operated by an authorized distributor that is used for the distribution of electricity from:</p> <p>Grid Supply Points or generation sets or other entry Points to the points of delivery to:</p> <p>Customers or Users or any transmission licensee in its capacity as operator of that licensee's transmission system or the Great Britain (GB) transmission system and includes any remote transmission assets (owned by a transmission licensee within England and Wales) that are operated by that authorized distributor and any electrical plant, electricity meters, and metering equipment owned or operated by it in connection with the distribution of electricity but does not include any part of the GB transmission system.</p>
Electricity Distribution License	The Electricity Distribution License granted or treated as granted pursuant to section 6(1) of the Electricity Act 1989.
Electricity Distributor	Any Person who is authorized by an Electricity Distribution License to Distribute electricity
High Voltage (HV)	Nominal Voltages of at least 1kV and less than 22kV
kV	Kilovolt
Regulation	Regulation (EU 2019/943 of the European Parliament and of the Council of 5 June 2019 on the international market for electricity (recast)
Use of system charges	Charges which are applicable to those parties which use the Distribution System.